



Emergency Charger for iPod and Motorola Razr

(FN-EC2088)

User's Manual

Instructions:

1. Unscrew bottom of the emergency charger.
2. Insert a single AA battery into the emergency charger, positive terminal first.
3. Screw the bottom cover back on the emergency charger.
4. Connect your phone or iPod specific connector to the emergency charger.
5. Connect your Phone or iPod to the Connector
 - *Emergency Charger will begin flashing
 - *If the emergency charger does not flash, check the connection or insert a new battery
6. Your Phone or iPod should indicate stop flashing when the charger process has completed.
7. To stop charging, remove the connector from the Phone or iPod.
 - *The charger unit will stop flashing within 10 seconds
8. The emergency charger may become warm during the charging process. This is normal.

This emergency charger comes with a one-year warranty.

Fashionation by Merkurs Innovations LLC.

180 Maiden Lane

28th Floor

New York, NY 10038